

### 3 Modulation and Communication Channels

#### 3.1 Introduction to Modulation

**Definition 3.1.** The term **baseband** is used to designate the band of frequencies of the signal delivered by the source.


**Example 3.2.** In telephony, the baseband is the audio band (band of voice signals) of 0 to 3.5 kHz.

**Definition 3.3. Modulation**<sup>11</sup> is a process that causes a shift in the range of frequencies in a signal.

- Fundamental goal: produce an information-bearing modulated wave whose properties are best suited to the given communication task.
- The part of the system that performs this task is called the **modulator**.

**Definition 3.4.** In **baseband communication**, baseband signals are transmitted without modulation, that is, without any shift in the range of frequencies of the signal.

3.5. Recall the frequency-shift property:



$$e^{j2\pi f_c t} g(t) \xrightarrow[\mathcal{F}^{-1}]{\mathcal{F}} G(f - f_c)$$

This property states that multiplication of a signal by a factor  $e^{j2\pi f_c t}$  shifts the spectrum of that signal by  $\Delta f = f_c$ .

<sup>11</sup>More general definition: modulation is the systematic alteration of one waveform, called the carrier, according to the characteristics of another waveform, the modulating signal or message.

3.6. Frequency-shifting (frequency translation) is easily achieved by “multiplying”  $g(t)$  by a sinusoid:

Two shifted and scaled copies (replicas) of  $G(f)$

$$g(t) \cos(2\pi f_c t) \xrightleftharpoons[\mathcal{F}^{-1}]{\mathcal{F}} \frac{1}{2} (G(f - f_c) + G(f + f_c)). \quad (28)$$





$$\begin{aligned} \cos(x) &= \frac{1}{2} (e^{jx} + e^{-jx}) \\ \cos(2\pi f_c t) &= \frac{1}{2} (e^{j2\pi f_c t} + e^{-j2\pi f_c t}) \\ g(t) \times & \downarrow \\ &= \frac{1}{2} g(t) e^{j2\pi f_c t} + \frac{1}{2} g(t) e^{-j2\pi f_c t} \end{aligned}$$

Alternatively,

$$\begin{aligned} \cos(2\pi f_c t) &\xrightarrow{\mathcal{F}} \frac{1}{2} \delta(f - f_c) + \frac{1}{2} \delta(f + f_c) \\ g(t) \times &\downarrow \mathcal{F} \\ &= \frac{1}{2} G(f - f_c) + \frac{1}{2} G(f + f_c) \end{aligned}$$

$$\xrightarrow{\mathcal{F}} \frac{1}{2} G(f - f_c) + \frac{1}{2} G(f - (-f_c))$$

$G(f)$  shifted to the right by  $f_c$        $G(f)$  shifted to the left by  $f_c$



To prevent overlapping  
 $f_c - B > -f_c + B$   
 $2f_c > 2B$   
 $f_c > B$

3.7. Similarly,

$$g(t) \cos(2\pi f_c t + \phi) \xrightleftharpoons[\mathcal{F}^{-1}]{\mathcal{F}} \frac{1}{2} (G(f - f_c) e^{j\phi} + G(f + f_c) e^{-j\phi}). \quad (29)$$


**Example 3.8.** Plot (by hand) the Fourier transforms of the following signals:

$$2\pi(10)t$$

(a)  $\cos(20\pi t)$




(b)  $(\cos(20\pi t))^2 = \underbrace{\cos(20\pi t)}_{g(t)} \times \cos(20\pi t)$



(c)  $\underbrace{\cos(20\pi t)}_{g(t)} \times \cos(40\pi t)$




(d)  $\underbrace{(\cos(20\pi t))^2}_{g(t)} \times \cos(40\pi t)$



**Definition 3.9.** The sinusoidal signals  $\cos(2\pi f_c t)$  in (28) and  $\cos(2\pi f_c t + \phi)$  in (29) are called the (sinusoidal) **carrier signals** and  $f_c$  is called the **carrier frequency**. In general, it can also have amplitude  $A$  and hence the general expression of the carrier signal is  $A \cos(2\pi f_c t + \phi)$ .

**Definition 3.10.** Communication that uses modulation to shift the frequency spectrum of a signal is known as **carrier communication**. [4, p 151]

**Definition 3.11.** We will use  $m(t)$  to denote the baseband signal. We will assume that  $m(t)$  is **band-limited to  $B$** : that is,  $|M(f)| = 0$  for  $|f| > B$ . Note that we usually call it the **message** or the **modulating signal**.



**Example 3.12.** A (Theoretically) Simple Modulator: Consider a **message**  $m(t)$  produced by a source. Let the transmitted signal be

$$x(t) = \sqrt{2} \cos(2\pi f_c t) \times m(t).$$

Then,

$$X(f) = \frac{\sqrt{2}}{2} M(f - f_c) + \frac{\sqrt{2}}{2} M(f + f_c).$$

The block diagram for this modulator is shown in Figure 4 which also includes an example of the amplitude spectrum  $|M(f)|$  for the message  $m(t)$ . With the given message spectrum and the carrier frequency being  $f_c$ , the amplitude spectrum  $|X(f)|$  for the transmitted signal  $x(t)$  is also shown.




Figure 4: A simple modulator along with the amplitude spectrum plots of the signals.

**Example 3.13.** In Figure 5, an audio signal is used as the message  $m(t)$ .




Figure 5: Signals in a simple modulator when an audio signal is used as its message.

## modulation + demodulation = modem

**Definition 3.14.** The process of recovering the signal from the modulated signal (retranslating the spectrum to its original position) is referred to as **demodulation**, or **detection**.

**3.15.** Modulation (spectrum shifting) benefits and applications:

(a) **Reasonable antenna size:**

- For **effective radiation of power** over a radio link, the **antenna size must be on the order of the wavelength**<sup>12</sup> of the signal to be radiated.
- **“Too low frequency” = “too large antenna”**
- **Audio** signal frequencies are so low (wavelengths are so large) that impracticably large antennas will be required for radiation.
  - Shifting the spectrum to a higher frequency (a smaller wavelength) by modulation solves the problem.

Voice :  $3 \text{ kHz} = 3 \times 10^3 \text{ Hz}$

$$c = f\lambda \Rightarrow \lambda = \frac{c}{f} = \frac{3 \times 10^8}{3 \times 10^3} = 10^5 = 100 \text{ km}$$

Mount Everest: 9 km

$3 \text{ GHz} \rightarrow \lambda = \frac{c}{f} = \frac{3 \times 10^8}{3 \times 10^9} = \frac{1}{10} = 10 \text{ cm}$

space flight starts here.

(b) **Frequency Assignment, Frequency-Division Multiplexing (FDM) and Frequency-Division Multiple Access (FDMA):**

- If several signals (for example, all radio stations), each occupying the same frequency band, are transmitted simultaneously over the same transmission medium, they will all interfere.
  - Difficult to separate or retrieve them at a receiver.
  - One solution is to use modulation whereby each radio station is **assigned** a distinct carrier frequency.

<sup>12</sup>Efficient line-of-sight radio propagation requires antennas whose physical dimensions are at least 1/10 of the signal's wavelength. [C&C [3], p. 8]

- \* Each station transmits a modulated signal, thus shifting the signal spectrum to its allocated band, which is not occupied by any other station.
- \* When you **tune** a radio or television set to a particular station, you are selecting one of the many signals being received at that time.
- \* Since each station has a different assigned carrier frequency, the desired signal can be separated from the others by filtering.

FD = freq. division

- **Multiplexing** is the process of combining (at the *local* level) several signals for simultaneous transmission on a common communications resource.
- **Multiple access** (MA) involves *remote* sharing of the resource.



(c) **Channel** passband matching.

$$a_1 x_1(t) + a_2 x_2(t) \rightarrow a_1 y_1(t) + a_2 y_2(t)$$

### 3.2 Communication Channel: Signal Distortion in Transmission

3.16. Recall that, for a **linear**, time-invariant (LTI) system, the input-output relationship is given by

$$y(t) = h(t) * x(t)$$

$$x(t) \rightarrow y(t)$$

$$x_1(t) \rightarrow y_1(t)$$

$$x_2(t) \rightarrow y_2(t)$$

$$a x(t) \rightarrow a y(t)$$

where  $x(t)$  is the input,  $y(t)$  is the output, and  $h(t)$  is the **impulse response** of the system.

Ex.

$y(t) = 3x(t) + 1$  ← affine

$x=2 \rightarrow y=7$   
 $x=4 \rightarrow y=13$   
 (Note:  $7 \times 2 = 14 \neq 13$ )

Not linear!



When  $x(t) = \delta(t)$ ,

$$y(t) \equiv h(t) * x(t) = h(t) * \delta(t) = h(t)$$

$$x_1(t) + x_2(t)$$


$$\rightarrow y_1(t) + y_2(t)$$

In which case,

$$Y(f) = H(f)X(f)$$

where  $H(f)$  is called the **transfer function** or **frequency response** of the system.  $|H(f)|$  and  $\angle H(f)$  are called the **amplitude response** (or gain) and **phase response**, respectively. Their plots as functions of  $f$  show at a glance how the system modifies the amplitudes and phases of various sinusoidal inputs.

**Example 3.17.** An “extremely nice” channel that does nothing to its input:




**Definition 3.18.** A channel is called **distortionless** if

$$y(t) = \beta x(t - \tau),$$

where  $\beta$  and  $\tau$  are constants.

- The channel output has the same “shape” as its input.
- This is the “best” channel we can hope for. Any transmitted signal  $x(t)$  will need to travel over some distance before it reaches the receiver. It will be delayed by the propagation time and its power will be attenuated.



- A channel is distortionless if and only if it satisfies two properties:


(a) “flat” frequency response: constant amplitude response

(b) linear phase shift

$$|H(f)| \equiv |\beta|$$

$$\angle H(f) \equiv \ominus (2\pi\tau)f \pm m180^\circ$$

negative linear phase shift



### 3.19. Major types of distortion

(a) Linear distortion


(i) Amplitude distortion (frequency distortion):  $H(f)$  is not constant with frequency.

$$|H(f)| \neq |\beta|$$

(ii) Phase distortion (delay distortion): the phase shift is not linear; the various frequency components suffer different amounts of time delay

(b) Nonlinear distortion: occur when the system includes nonlinear elements

Ex1  $y(t) = (x(t))^2$   
 “memoryless”



### Example 3.20. Amplitude distortion (frequency distortion)

(a) Figure 6 shows signals in a channel with low-frequency attenuation





Figure 6: Channel with low-frequency attenuation








Figure 7: Channel with high-frequency attenuation

(b) Figure 7 shows signals in a channel with high-frequency attenuation

**Example 3.21.** A common area of confusion is **constant time delay** versus **constant phase shift**. The former is desirable and is required for distortionless transmission. The latter, in general, causes distortion.

(a) Figure 8 shows signals in a channel with **constant phase shift**





Figure 8: Channel with constant phase shift

- Note that the peaks of the phase-shifted signal are substantially greater (by about 50 percent<sup>13</sup>) than those of the input test signal.
  - This is because the components of the distorted signal all attain maximum or minimum values at the same time, which was not true of the input.
- Frequency response:

$$H(f) = \begin{cases} 1e^{j\frac{\pi}{2}}, & f \geq 0, \\ 1e^{-j\frac{\pi}{2}}, & f < 0, \end{cases} = \begin{cases} j, & f \geq 0, \\ -j, & f < 0. \end{cases}$$

<sup>13</sup>Delay distortion is crucial in pulse transmission. On the other hand, an untrained human ear is insensitive to delay distortion. Thus, delay distortion is seldom of concern in voice and music transmission.



(b) Figure 9 shows signals in a channel with **linear phase shift** (wrt. the freq.)




Figure 9: Channel with linear phase shift

Note that

$$\begin{aligned}
 y(t) &= \cos\left(t + \frac{\pi}{2}\right) - \frac{1}{3}\cos\left(3t + 3\frac{\pi}{2}\right) + \frac{1}{5}\cos\left(5t + 5\frac{\pi}{2}\right) \\
 &= \cos\left(t + \frac{\pi}{2}\right) - \frac{1}{3}\cos\left(3\left(t + \frac{\pi}{2}\right)\right) + \frac{1}{5}\cos\left(5\left(t + \frac{\pi}{2}\right)\right) \\
 &= x\left(t + \frac{\pi}{2}\right)
 \end{aligned}$$

Therefore, this **linear phase shift is the same as the time-shift operation.**

### 3.22. Multipath Propagation and Time Dispersion [6, p 1]

- In *wireless* channel, the presence of multiple scatterers (buildings, vehicles, hills, and so on) causes the transmitted radio wave to propagate along several different paths (rays) that terminate at the receiver. Hence, the receive antenna picks up a superposition of *multiple attenuated and delayed copies* of the transmitted signal.

This phenomenon is referred to as **multipath propagation**. [6, p 1]


- Due to different lengths of the propagation paths, the individual multipath components experience different delays (time shifts) [6, p 1]:

$$y(t) = x(t) * h(t) = \sum_{i=0}^v \beta_i x(t - \tau_i)$$

where

$$h(t) = \sum_{i=0}^v \beta_i \delta(t - \tau_i)$$

31



$$h(t) = 0.9 \delta(t - 5ms) + 0.5 \delta(t - 10ms)$$




Figure 10: Multipath Propagation

Here,  $\beta_i = |\beta_i|e^{j\phi_i}$  and  $\tau_i$  are, respectively, the complex attenuation factor and delay associated with the  $i$ th path.

- The receiver observes a temporally smeared-out version of the transmit signal. Such channels are termed **time-dispersive**
- The corresponding frequency response of the channel is

$$H(f) = \sum_{i=0}^v \beta_i e^{-j2\pi f\tau_i} \quad (30)$$


- Time-dispersive channels are **frequency-selective** in the sense that different frequencies are attenuated differently. This is clear from the  $f$ -dependent  $H(f)$  in (30).
  - These differences in attenuation become more severe when the difference of the path delays is large and the difference between the path attenuations is small. [6, p 3]
    - \* This can be seen from the expression in Ex. 3.23.
- Although multipath propagation has traditionally been viewed as a transmission impairment, nowadays there is a tendency to consider it as beneficial since it provides additional degrees of freedom that are known as delay diversity or frequency diversity and that can be exploited to realize diversity gains or, in the context of multiantenna systems, even multiplexing gains. [6]

$$y(t) = \beta_1 x(t - \tau_1) + \beta_2 x(t - \tau_2)$$

Let's set  $x(t) = \cos(2\pi f_c t)$  

$$\begin{aligned} y(t) &= \beta_1 \cos(2\pi f_c (t - \tau_1)) + \beta_2 \cos(2\pi f_c (t - \tau_2)) \\ &= \beta_1 \cos(2\pi f_c t - \underbrace{2\pi f_c \tau_1}_{\theta_1}) + \beta_2 \cos(2\pi f_c t - \underbrace{2\pi f_c \tau_2}_{\theta_2}) \\ &= \underbrace{\beta_1 \cos(2\pi f_c t + \theta_1)} + \underbrace{\beta_2 \cos(2\pi f_c t + \theta_2)} \\ &= \beta \cos(2\pi f_c t + \theta) \end{aligned}$$

Ex.  $\cos(t) + \sin(t) = \cos(t) + \cos(t - 90^\circ)$



Ex.  $4 \cos(2t) + 3 \sin(2t) = 5 \cos(2t - 36.87^\circ)$

$$\begin{aligned} &\updownarrow \quad \updownarrow \\ &4 \angle 0^\circ + 3 \angle -90^\circ = 5 \angle -36.87^\circ \end{aligned}$$



**Example 3.23. Two-path channel:** Consider two propagation paths in a static environment. The receive signal is given by

$$y(t) = \beta_1 x(t - \tau_1) + \beta_2 x(t - \tau_2).$$

In which case,

$$h(t) = \beta_1 \delta(t - \tau_1) + \beta_2 \delta(t - \tau_2)$$

and

$$H(f) = \beta_1 e^{-j2\pi f \tau_1} + \beta_2 e^{-j2\pi f \tau_2} = |\beta_1| e^{j\phi_1} e^{-j2\pi f \tau_1} + |\beta_2| e^{j\phi_2} e^{-j2\pi f \tau_2}.$$

Recall that  $|Z_1 + Z_2|^2 = |Z_1|^2 + |Z_2|^2 + 2\text{Re}\{Z_1 Z_2^*\}$ . Therefore,

$$|H(f)|^2 = |\beta_1|^2 + |\beta_2|^2 + 2\text{Re}\left\{|\beta_1| e^{j\phi_1} e^{-j2\pi f \tau_1} (|\beta_2| e^{j\phi_2} e^{-j2\pi f \tau_2})^*\right\}$$


$$= |\beta_1|^2 + |\beta_2|^2 + 2\text{Re}\left\{|\beta_1| |\beta_2| e^{j(\phi_1 - 2\pi f \tau_1 - \phi_2 + 2\pi f \tau_2)}\right\}$$

$$\text{Re}\{e^{j\alpha}\} = \cos \alpha$$

$$= |\beta_1|^2 + |\beta_2|^2 + 2|\beta_1||\beta_2| \cos(2\pi(\tau_2 - \tau_1)f + (\phi_1 - \phi_2)).$$

$$\cos(2\pi f_0 x)$$

↑  
freq  
period =  $\frac{1}{f_0}$



Large  $|\tau_2 - \tau_1| \rightarrow$  faster oscillation

Small  $|\tau_2 - \tau_1| \rightarrow$  slower oscillation

$$(\beta_1 - \beta_2)^2 \geq 0$$

$$\beta_1^2 + \beta_2^2 - 2\beta_1\beta_2 \geq 0$$

Define the depth of the oscillation


$$\equiv \frac{4|\beta_1||\beta_2|}{|\beta_1|^2 + |\beta_2|^2 + 2|\beta_1||\beta_2|}$$

depth is large when  $|\beta_1| \approx |\beta_2|$

small when  $|\beta_1| \gg |\beta_2|$  or

$|\beta_1| \ll |\beta_2|$

$$= \frac{4}{\frac{|\beta_1|}{|\beta_2|} + \frac{|\beta_2|}{|\beta_1|} + 2} = \frac{4}{r + \frac{1}{r} + 2}$$



**Example 3.24.** Consider the two-path channels in which the receive signal is given by

$$y(t) = \beta_1 x(t - \tau_1) + \beta_2 x(t - \tau_2).$$

Four different cases are considered.

- (a) Small  $|\tau_1 - \tau_2|$  and  $|\beta_1| \gg |\beta_2|$
- (b) Large  $|\tau_1 - \tau_2|$  and  $|\beta_1| \gg |\beta_2|$
- (c) Small  $|\tau_1 - \tau_2|$  and  $|\beta_1| \approx |\beta_2|$
- (d) Large  $|\tau_1 - \tau_2|$  and  $|\beta_1| \approx |\beta_2|$




Figure 11: Frequency selectivity in the receive spectra (blue line) for two-path channels.

Figure 11 shows four plots of the normalized<sup>14</sup>  $|X(f)|$  (dotted black line<sup>15</sup>) and the normalized  $|Y(f)|$  (solid blue line) in [dB]. Match the four graphs (i-iv) to the four cases (a-d).

<sup>14</sup>The function is normalized so that the maximum point is 0 dB.

<sup>15</sup>For those who are curious,  $x(t)$  is a raised cosine pulse with roll-off factor  $\alpha = 0.2$  and symbol duration  $T = 0.5$ .