ECS455: Chapter 4

Multiple Access

4.3 DS/SS



Office Hours: BKD, 6th floor of Sirindhralai building Tuesday 14:20-15:20 Wednesday 14:20-15:20 Friday 9:15-10:15

Spread spectrum (SS)

- Historically spread spectrum was developed for <u>secure</u> communication and <u>military</u> uses.
- **Difficult to intercept** for an unauthorized person.
- Easily hidden.
 - Can even hide below the noise floor during transmission
 - For an unauthorized person, it is **difficult to even detect their presence** in many cases.
- Resistant to narrowband jamming and interference.

Spread spectrum (SS)

- Provide a measure of immunity to distortion due to multipath propagation.
 - In conjunction with a RAKE receiver, can provide coherent combining of different multipath components.
- Asynchronous multiple-access capability.
- Wide bandwidth of spread spectrum signals is useful for location and timing acquisition.
- Applications
 - Cordless phones.
 - The basis for both 2nd and 3rd generation **cellular systems** as well as 2nd generation wireless LANs (**WLAN**).

3

[Goldsmith, 2005, Ch 13]

Spread spectrum: Definition

Spread spectrum refers to any system that satisfies the following conditions [Lathi, 1998, p 406 & Goldsmith, 2005, p. 378]:

- 1. The spread spectrum may be viewed as a kind of modulation scheme in which **the modulated (spread spectrum) signal bandwidth is much greater than the message** (baseband) signal bandwidth.
- 2. The **spectral spreading** is performed by a **code** that is **independent** of the message signal.
 - This same code is also used at the receiver to despread the received signal in order to recover the message signal (from the spread spectrum signal).
 - In secure communication, this code is known only to the person(s) for whom the message is intended.

[R. Pickholtz, D. Schilling, L. Milstein, "Theory of Spread-Spectrum Communications - A Tutorial," IEEE Trans. Commun., Vol. 30, pp. 855-884, May 1982.]

SS: Processing Gain and BW Sharing

- Increase the bandwidth of the message signal by a factor *N*, called the **processing gain** (or bandwidth **spreading factor**).
 - In practice, N is on the order of 100-1000. [Goldsmith, 2005, p 379]
 - *N* = 128 for IS-95 [T&V]
 - Wasteful?
- **Bandwidth Sharing**: Although we use much higher BW for a spread spectrum signal,
 - **Multiplexing**: we can also multiplex large numbers of such signals over the <u>same</u> band.
 - **Multiple Access**: many users can share the same spread spectrum bandwidth without interfering with one another.
 - Achieved by assigning different code to each user.
 - Frequency bands can be reused without regard to the separation distance of the users.



Two forms of spread spectrum

1. Frequency Hopping (FH)

- Hop the modulated data signal over a wide BW by changing its carrier frequency
- BW is approximately equal to *NB*
- *N* is the number of carrier frequencies available for hopping
- *B* is the bandwidth of the data signal.
- The most celebrated invention of frequency hopping was that of actress Hedy Lamarr and composer George Antheil in 1942





2. Direct Sequence (DS)

FHSS Example: Bluetooth

- The band at 2.4 GHz is divided into 79 channels.
- A Bluetooth device, hops frequency at a rate of 1600 hops per second, randomly selecting a channel of 1 MHz to operate.





DS/SS System (Con't)

Observe that...

- To be able to perform the despreading operation, the receiver must
 - **know** the **code** sequence *c*(*t*) used at the Tx to spread the signal
 - **synchronize** the codes of the received signal and the locally generated code.
- The process of detection (despreading) is **identical** to the process of spectral spreading.
 - Recall that for DSB-SC, we have a similar situation in that the modulation and demodulation processes are identical (except for the output filter).





DS/SS System: Signals

- During the time that m(t) = 1, the spreading code is non-inverted in x(t).
 - in c(t) = 1

 $x(t) = m(t)c(t) \quad y(t) = x(t)$

m(t)

 During the time that m(t) = -1, the spreading code is inverted (or negated) in x(t).





- The bit rate of *c*(*t*) is chosen to be much higher then the bit rate of *m*(*t*).
- In fact, by definition, the spreading factor $N = \frac{T_b}{T_c}$.





Frequency-Domain Analysis





- As *N* increases, the peak of *X*(*f*) is reduced.
- Secure communication
 - Signal can be detected only by **authorized** person(s) who **know** the pseudorandom code used at the transmitter.
 - Signal spectrum is spread over a very wide band, the signal's **spectral level is very small**, which makes it easier to hide the signal within the noise floor

SS Modem



DS/SS: Jamming Resistance



$y(t)c(t) = (x(t)+i(t))c(t) = m(t)c^{2}(t)+i(t)c(t) = m(t)+i(t)c(t)$

- Jamming Resistance / Narrowband Interference rejection
 - The decoder despreads the signal y(t) to yield m(t).
 - The jamming signal i(t) is spread to yield i(t)c(t).
 - Using a LPF, we can recover *m*(*t*) with only a small fraction of the power from *i*(*t*).
- Caution: Channel noise will not spread.